

# 488.2 Errata

---

## E.1 INTRODUCTION

This Errata contains additional information and changes to the 488.2 Manual since its latest release. These changes require that you are using a GPIB-32.DLL version 2.0.9.1 or later. If you do not have the latest driver, you can download the current installer from ICS Electronics' website.

## E.2 ADDED CABLE LENGTH PARAMETER

An `ibcHSCableLength` parameter was added to the `ibConfig` command and to table 6-6 on page 6-50 of the 488.2 Manual.

**TABLE 6-6 IBCONFIG CONFIGURATION OPTIONS**

Option	For	Description
<code>IbcCableLength</code>	bd	Enables/Disables HS488 Handshaking. If the value is 0 then the HS488 high speed handshaking will be disabled. A value between 1 and 15 defines the number of meters of GPIB cable in your system. ICS does not support handshaking above 1 Mbs so the <code>IbcCableLength</code> setting has no affect on the operation of your GPIB Controller. This parameter is supplied for compatibility with the NI-488.2 software.