

4892 Errata

E.1 INTRODUCTION

This Errata contains additional information and changes to Revision 0 of the 4892 Instruction Manual

E.2 COMPANY ADDRESS

ICS Electronics new address is:

ICS Electronics
7034 Commerce Circle, Pleasanton, CA 94588
Phone: 925-416-1000, Fax: 925-416-0105

E.3 FORMFEED COMMAND

New command added to the 4892's SCPI command tree to generate a formfeed character when the GPIB buffer becomes empty. An updated SCPI Command Tree is shown in Table E-1.

The FORMfeed command definition is shown in Table E-2.

TABLE E-1 4892 SCPI COMMAND TREE

Keyword	Parameter Form	Notes
SYSTem		
:EMULation	ICS NI	
:MODE	G P	
:PMODE	CONTROLLER DEVICE TALK ONLY	
:TEST	-----	(command only)
:OPERation	COMMAND DATA	
:COMMunicate		
:GPIB		
:ADDRESS	<numeric value>	
:BUFFer?	[query only]	
:FORMfeed	1 [0]	enables formfeed
:ERRor?	[query only]	
:VERSion?	[query only]	1991.0
STATus		
:OPERation		
[:EVENT]?	[query only]	
:CONDition?	[query only]	
:ENABLE	<numeric value>	
:QUESTionable		
[:EVENT]?	[query only]	
:CONDition?	[query only]	
:ENABLE	<numeric value>	
:PRESet	-----	(command only)

TABLE E-2 SCPI COMMANDS AND QUERIES

Keyword	Default Value	Description
FORMfeed	0	Enables the 4892 to generate a formfeed character (0x0C) when the buffer becomes empty. The user should be careful to transfer all of the data for a page at one time so the buffer does not become empty while printing the page when FORMfeed is enabled. Values are 0 for off and 1 for on.